

SKIN+ACT



Elite Portable High Frequency 7 Glass Tubes

USER MANUAL



User Instruction

Thank you for purchasing our portable facial wand. To ensure that understand the performance and operation of this product, please read the user instruction carefully before using.

For use this product safety, the instruction is as follow:

- Read the instruction detail carefully and take care of it for future reference.
- Follow correct operation instruction when use this product.
- All users don't disassemble and change the original component/accessories for this product,except the professional electrician.
- If you have any problem for the operation, please contact the supplier or distributor for further help.
- This product doesn't belong to medical equipment. Don't use it to any diseases treatment.

1. Main Instruction

Portable Facial Wand is a very important beauty care instrument. It is professional grade and perfect for home or spa use. This machine through the glass tube to apply to the facé. Glass tubes generate a warming effect on the skin, and they are gentle and perfect for oily or combination skin. This machine is used to the gentle skin treatment, thus achieves the skin care treatment result.

2. Operation Method

A: Use corresponding glass tube for different place on the face.

1. Mushroom glass tube for broad treatment areas such as the forehead.
2. Bar glass tube useful for décolletage or larger areas.
3. Spoon glass tube for sensitive areas such as dark circles/bags beneath eyes.
4. Comb glass tube for hair area.
5. Clean and disinfect the glass tube with medical alcohol every time before using.
6. Insert the glass tube into the outlet.
7. Apply the cream to the skin and keep the skin smooth.
8. Turn on the switch and adjust the output knob to ensure that the output intensity is properly. **Notice:** Ensure that adjust the output knob first,and then test the output intensity if it is appropriate by hand before apply it to theclients
9. Operation has finished, be sure to take off the glass tube and disinfect the glass tube.



Notice: Ensure that adjust the output knob first, and then test the output intensity if it is appropriate by hand before apply it to the clients

F: Operation has finished, be sure to take off the glass tube and disinfect the glass tube.

3. Cautions:

- If the power cord is damaged, replace it with the same kind of power cord or refer to professional technician for repairing.
- Keep the machine clean after use to avoid the accumulation of oil and other debris.
- This product is used for a barber shop, beauty salon, or similar places.
- This machine is not suit for using by the person who has weak constitution, reaction slow or psychosis (include children), unless it guide by the person who had safe responsibility and safe use.
- The children should be supervised and make sure that they are not playing the machine.
- This product does not belong to medical equipment, please do not used for the treatment of diseases.

4. Technical data:

Volt: 220V-240V

Frequency: 50Hz/60Hz or Frequency: 50Hz/60Hz

Power: 2W

Note: Two kinds of electrical system as the above, you refer to our product nameplate which mark on the machine that you purchase.

5. Accessories

1. Handle
2. Mushroom Glass Tube
3. Bar Glass Tube
4. Spoon Glass Tube
5. Comb Glass Tube
6. Roller Tube
7. Y Tube
8. Spot Tube
9. User Instruction