

Hair Dryer With Timer (SKU16211)



SKIN+ACT

Toll Free: 1.800.418.0830

www.skinact.com
www.spaandequipment.com

International: 818.834.6640

NOTICE

No part of this document may be photocopied, reproduced, or translated into any other language without prior written consent of Spa and Equipment/SkinAct.

The information in this document is subject to change without notice at any time and should not be construed as a commitment by Spa and Equipment/SkinAct.

Spa and Equipment/SkinAct assumes no responsibility for any errors that may be in this document, nor does it make expressed or implied warranty with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Spa and Equipment/SkinAct shall not be liable for incidental or consequential damages arising out of the furnishing, performance, or use of this document and the program material which it describes.

SKIN+ACT

Toll Free: 1.800.418.0830	www.skinact.com www.spaandequipment.com	International: 818.834.6640
---------------------------	--	-----------------------------

Thank you very much for purchasing our Hair Dryer. Please read this User Manual carefully before use. Once you are familiar with the instructions, you will be able to enjoy its excellent performance and safe operation.

1. Functions

- Automatic temperature control for consistent results.
- Even and gentle airflow to protect hair.
- Multi-purpose use: hair drying, evening hairstyles, conditioning treatments, and pigmentation care.



Control panel (Time, Wind Velocity, and Temperature dials)

2. How to Use

A. Before first use

Open the package and check if any parts are loose from transportation. If so, tighten them before operation.

B. Operation steps

- 1 Plug the unit into a 220V power supply.
- 2 Turn the time switch clockwise to set a duration (0–60 minutes).
- 3 Press the power switch.
- 4 Select the desired temperature between 0–70°C.

C. After use

Always disconnect the power supply for safety.



Open canopy position for easy access.

3. Safety Precautions

- When adjusting the vertical tube, hold the top firmly and adjust slowly to the desired height.
- Do not allow any objects to fall into the machine while it is operating, as this may cause damage.
- Always operate the device on a stable and level surface.
- Keep the unit away from water or moisture to prevent electric shock.

4. Main Components

- 1) Time Switch
- 2) Wind Velocity Switch
- 3) Temperature Control
- 4) Hair Drying Canopy
- 5) Height Adjustment Knob
- 6) Force Bouncing Tube
- 7) Foot Rack
- 8) Fixing Screw

