

# UV Sterilizer (SKU16183)



**SKIN+ACT**

Toll Free: 1.800.418.0830

[www.skinact.com](http://www.skinact.com)  
[www.spaandequipment.com](http://www.spaandequipment.com)

International: 818.834.6640

## NOTICE

No part of this document may be photocopied, reproduced, or translated into any other language without prior written consent of Spa and Equipment/SkinAct.

The information in this document is subject to change without notice at any time and should not be construed as a commitment by Spa and Equipment/SkinAct.

Spa and Equipment/SkinAct assumes no responsibility for any errors that may be in this document, nor does it make expressed or implied warranty with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Spa and Equipment/SkinAct shall not be liable for incidental or consequential damages arising out of the furnishing, performance, or use of this document and the program material which it describes.

# SKIN+ACT

|                           |  |                             |
|---------------------------|--|-----------------------------|
| Toll Free: 1.800.418.0830 | <a href="http://www.skinact.com">www.skinact.com</a><br><a href="http://www.spaandequipment.com">www.spaandequipment.com</a> | International: 818.834.6640 |
|---------------------------|--|-----------------------------|

## **1. Function**

Ionization generated by ultraviolet light from the sterilization tube, combined with ozone produced in the air, effectively eliminates E. coli, hepatitis B, and other harmful microorganisms. This device can be used for sterilizing towels and other facial or beauty tools that are not heat-resistant.

## **2. Main Technical Parameters**

- Power source: 220V/50Hz or 110V/50Hz
- Rated input power:  $\geq 15$  minutes
- Volume: 10L
- Electric shock protection category: Category I

## **3. Operating Instructions**

- Place the items to be sterilized on the bracket, then close the door of the box.
- Switch on the power, press the power switch, and check that the indicator light is on. Sterilization will begin inside the box.
- After sterilization is complete, turn off the power switch and remove the sterilized items for use.

## 4. Important Notes

- Always close the door before use and switch the unit on. Otherwise, ozone may leak, reducing the sterilization effect.
- Do not overlap items inside the box; otherwise, the sterilization effect may be reduced.
- Disconnect the power supply before cleaning. Use a soft cloth with a small amount of neutral detergent to wipe inside and outside the box. Then wipe with a clean, damp cloth to remove any residue.
- If you notice any malfunction or electrical failure, contact a qualified electrician for repair using parts with the same specifications.
- Use this machine strictly according to the operating rules. The manufacturer is not responsible for accidents or issues caused by improper operation.

